

# Stop Valve

## Quick to connect screw down mains stop valve

### Overview

Speedfit push-fit valve allows the user to stop the flow of water to a fixture or zone in the event of an emergency or for repair work. Simply push the valve fully onto the pipe. To demount the push-fit end, pull the collet towards the body of the fitting and pull the pipe to release.

The fitting is quicker and easier to install in confined spaces than traditional methods as it eliminates the need for hot works or tools.

Designed, manufactured and assembled in the UK.

### Features & Benefits

- Compact design is ideal for installing in areas where space is tight
- Instant push-fit connection and screw down mains to stop valve
- Install and demount in seconds without tools
- Safe flame-free installation, with no hot works, glue or flux
- Grip & Seal collet with stainless steel teeth and main O-Ring seal
- Suitable for use with JG Speedfit PEX and polybutylene barrier pipe (inserts required) and copper pipe
- Suitable for hot and cold water and central heating systems



Product code	Description	Size	Bag QTY
15STV	Stop Valve	15mm	1
22STV	Stop Valve	22mm	1



50 year guarantee when used with JG Speedfit Layflat PB and PEX Barrier Pipes

# Stop Valve

## Working parameters & specifications

Application	Usual working temperature °C	Maximum working temperature °C	Maximum working pressure, bar
Cold Water (indirect and direct mains)	20	20	12
Hot Water (including unvented cylinders)	65	95	6

Materials	
Body	Acetal Copolymer (Unfilled) White
O-Ring & Seals	Ethylene Polypropylene Diene Monomer (EPDM)
Collet	Acetal Copolymer (Unfilled) White,, Stainless Steel
Spindle	Nylon 66 (25% Glass Filled) White
Top Cover	Nylon 66 (25% Glass Filled) White
Handle	Acetal Copolymer, Stainless Steel, EPDM Silicone
Retaining Rings	Acetal Copolymer (Unfilled) Grey
Support Washer	Acetal Copolymer (Unfilled) Natural
Seal Carrier	Acetal Copolymer (30% Glass filled) Natural

## Dimensions – All measurements in mm unless otherwise stated

